



TRACKER™

TR-1

User's Manual v1.3

Table of Contents

Page

COMPONENTS RECEIVED	2
COMPONENTS NOT INCLUDED.....	2
CONNECTION PANEL.....	2
INSTALLATION.....	2
TRACKER™ OPERATIONS	3
1. Quick Start Guide	3
2. "Update Job Information" Screen	3
3. "Update Tracker Settings" Screen	4
4. Start Job, End Job, and Clear Counts	5
5. Percentage Fields	5
6. Andon Lights	6
7. Job Status Mode Screen	6
TROUBLE SHOOTING.....	7
TECHNICAL INFORMATION.....	7

Manual Color Key:

Display Field

Button

COMPONENTS RECEIVED

1. **TRACKER™ TR-1:** Part Number – (OT-60002)
2. Sensor Assembly:
 - a. Diffuse Reflective Sensor: Part Number – (OT-6000208)
 - b. Sensor Cable: Part Number – (OT-6000209)
 - c. Mounting Assembly: Part Number – (OT-6000213)
3. Current version manual.




COMPONENTS NOT INCLUDED

1. HDMI TV Screen (720p or compatible)
2. Keyboard and Mouse (USB Cable or Wireless USB)
3. HDMI Cable
4. Manual and Technical Documents available online at TrackMyOps.com/documents.html

CONNECTION PANEL

1. 115/230 Volt, 50/60Hz, 2 Amp Power Cord
2. Power ON/OFF Switch
3. Fuse Holder (Fuse Size 500ma FA)
4. M12 Sensor Plug (4 wire, 24V, NPN)
5. Female Ethernet Port (Wired)
6. Female HDMI Standard Port (720p or compatible)
7. Female USB 2.0 Port (Wired or Wireless)
8. Female USB 2.0 Port (Wired or Wireless)



INSTALLATION

Steps Prior to Powering Up Your Tracker TR-1

1. Plug in user provided keyboard and mouse.
2. Plug in user provided HDMI Cable to **Tracker TR-1's** HDMI port.
3. Plug in HDMI Cable to 720p TV HDMI port. **Note which HDMI input number.**
4. Mount included sensor to (manual or automated) production line in a position best suited to track the process.
 - a. Provided sensor has an approximate 2-inch range. See sensor specs for optional sensors.
 - b. Note: Ensure when powered up the sensor light is flashing yellow for each product as it passes.
 - i. If sensor light is steady on then it is reflecting on a background object.
 - ii. If sensor light does not turn yellow at all it is not "seeing" or reflecting off any object.
 - iii. Reposition as necessary.
5. Plug in **Tracker TR-1** power cord to standard 115V/230V wall outlet.
6. Turn ON TV and set to correct HDMI input number.

Powering Up Your Tracker TR-1

7. Switch the **Tracker TR-1** power switch ON.
8. Power up will last about 15 seconds.
9. Verify sensor is working properly and is in correct position (per instruction **4b** above).
10. The **Detected Count** field will increment at all times when the **Tracker TR-1** is powered up and the Sensor is detecting objects. The **Detected Speed** field will display line speed at all times when the **Tracker TR-1** is powered up and the sensor is detecting objects. This is true when system is in **START JOB** or **END JOB** mode. The **Detected Count** field will reset to zero ("0") when the **Clear** button is clicked.

Tracker TR-1 OPERATIONS


1. Quick Start Guide

- Enter identification information for Operators and current Job in the "Update Job Information" screen by clicking the [Update Job Info](#) button. Click **OK** or press 'Enter' on keyboard to save.
- Configure **Tracker TR-1** settings for specific machines (e.g. ID, multiplier, timeout counter, etc.) and other **Tracker TR-1** settings (e.g. HUB communication, sensor type, etc.) in the "Update Tracker Settings" screen by clicking the [Tracker Settings](#) button. Click **OK** or press "Enter" on keyboard to save.
- Click on the [Clear](#) button to zero ("0") **Detected Count** and **Target Count** fields.
- Click on the [Start Job](#) button to start.
- Start your (manual or automated) production line that the **Tracker TR-1** is monitoring.
- Tracker TR-1** will display the **Detected Counts** and **Detected Speed** (counts/hour) in real-time.
- If an hourly target goal for counts per hour is entered in **Update Job Info** in the **Target/Takt Speed** field, then **Tracker TR-1** will display:
 - Target/Takt Counts** as a pace counter,
 - Counts: % On Target** comparing **Detected Counts** to **Target/Takt Counts**,
 - Speed % On Target** comparing **Detected Speed** to **Target/Takt Speed**.
- If a Job Size is entered, **Tracker TR-1** will display **Job: % Complete** comparing **Detected Counts** to **Job Size**.
- If entered, **Tracker TR-1** will display the **Machine ID**, **Operator ID**, and **Job ID**.
- Click on the [End Job](#) button when job is complete.



2. "Update Job Information" Screen

- To view the "Update Job Information" screen, click on the [Update Job Info](#) button.
- Enter alpha-numeric **Operator ID** and **Job ID**.
- Enter numeric-only **Job Size**.
- Enter numeric only **Target/Takt Speed** as an hourly target rate (in counts per hour). This field will only display as a rate per hour.
For example: enter 100 per hour for a target of 100 hourly counts; for a target of 100 per half hour, you would enter 200; or for a target of 100 per two hours you would enter 50.
- When a value is entered in the **Target/Takt Speed** field, the **Tracker TR-1** will calculate the number of pieces that should have been produced from the start of the job, and will display and update this value in the **Target/Takt Counts** field. This field will continue to increment at the calculated rate for as long as the system is in START JOB mode and in a JOB STATUS that does not disable the TAKT. Reference page 6 for the different JOB STATUS and how they affect the **Target/Takt Counts** field
- To delete all text from fields, click the [Clear](#) button.
- A barcode scanner can be used for data entry by plugging a USB Scanner into a USB port. Each field can be represented by its own barcode where you will need to click in each field and scan the applicable barcode. To enter all fields at once, click in the Operator ID field, separate the fields with an underscore ("_") in the barcode data, scan the barcode, and click the [Split](#) button.
- To Save click on **OK**.



3. "Update Tracker Settings" Screen

- a. To view the "Update Tracker Settings" screen, click the **Tracker Settings** button. Once set, these settings should typically be constant and not need to change unless the **Tracker TR-1** is moved to another line or process.
- b. Enter alpha-numeric **Machine ID**.
- c. Set **Count Multiplier** as required.
 - i. The **Count Multiplier** default value is 1. Every time the sensor counts the value increments one. If you would like value to increment by more than 1, change **Count Multiplier** value.
For example, if you are running a 12 pack box of cans and the sensor just sees the box, but you would like to know how many cans have been run, change the value to 12.
- d. Set **Speed Multiplier** as required.
 - i. The **Speed Multiplier**: default value is 1. Enter any value to increment the speed by the **Speed Multiplier** value.
For example, if you are running a 12 pack box of cans and the sensor just sees the box, but you would like to know how many cans have been run, change the value to 12.
- e. Set **Pulse Timeout** as required.
 - i. Depending on the JOB STATUS selected, the system knows if it should be receiving sensor pulse inputs because line is running or if it should receive no sensor pulse inputs because line is not running. If the system detects counts when the JOB STATUS declares it should not be (or vice versa, when the system detects no counts in a JOB STATUS that requires them) it is in the wrong JOB STATUS mode, after the **Pulse Timeout** time period (in seconds) has expired, the system will start flashing all 4 of the Andon lights letting the operator know they need to select the correct JOB STATUS mode.
 - ii. *For example, if the Pulse Timeout value is set to 60 seconds and the system is in the RUNNING mode, but the production line has stopped and no sensor input pulses are received for 60 seconds, the system will start flashing all 4 Andon lights. When operator selects a JOB STATUS mode that is not expecting sensor inputs, (e.g. Down for Service), the system will turn off the 4 flashing Andon lights and activate the correct Andon light configuration for that JOB STATUS mode. See Section 8 below for additional information on JOB STATUS modes.*
- f. The **HUB IP Address** field is only applicable to users with **Tracker HUBs**. **This field should be left blank.** *Refer to the **Tracker HUB** manual to populate this field.
- g. Select the **Mechanical Limit Switch** box by clicking within the square only if you are using a variation of a mechanical switch and not using a photoelectric sensor. By default this option is not selected.
- h. Select the **Channel 2 Active** box to enable a second sensor for a dual sensor input. **This setting is only applicable if you have purchased a Tracker TR-2.** By default this option is not selected.
- i. The default Language for the TR controller is English. Additional languages and terminology can be configured with the **Tracker HUB**.
- j. **Wireless SSID and Passphrase** fields are for configuring a Wi-Fi access point enabling the TR controller to communicate wirelessly with a **Tracker HUB**. This field is only applicable to users with **Tracker HUBs**. **This field should be left blank.** *Refer to the **Tracker HUB** manual to populate this field.



4. Start Job, End Job, and Clear Counts

- a. On power up the **Tracker TR-1** is in END JOB mode. The END JOB mode is identified by the red background behind the **Detected Speed** and **Detected Counts** fields.
- b. To enter the START JOB mode, click on the **Start Job** button. The START JOB mode is identified by no color highlighting the **Detected Speed** and **Detected Counts** fields. When the **Start Job** button is clicked, the red background behind the **Detected Speed** and **Detected Counts** fields will turn off, and the **Target/Takt Counts** will begin incrementing. The JOB STATUS will flash the current start job state of RUNNING.
- c. To exit the START JOB mode and enter the END JOB mode, click on the **End Job** button.
- d. You will use the various JOB STATUS options to record different running conditions while stopping and starting your production line. Please reference page 6 for the definitions of available job statuses.
- e. Upon completion of the job, click **End Job** to move back to the END JOB mode. All counts and speed fields will show a red background. END JOB mode designates the end of a job. Utilize the JOB STATUS options to record downtime when a production line has stopped before the job is completed.
- f. Clicking the **Clear Counts** button will reset all counts back to zero.

5. Percentage Fields


- a. **Counts: % On Target** field: This displays the ratio between **Detected Counts** and **Target/Takt Counts** as a percentage (%). Formula is $\text{Detected Counts} / \text{Target/Takt Counts}$.
 - i. For 0 to 79% background is Red.
 - ii. For 80 to 94% background is Yellow.
 - iii. For 95 % and greater background is Green.
 - iv. **Please note:** if you place system in END JOB mode and click on **Clear Counts** button to set **Target/Takt Counts** to zero, the **Counts: % On Target** field will remain at ("0") zero.
- b. **Speed: % On Target** field: This displays the ratio between **Detected Counts** and **Target/Takt Speed** as a percentage. Formula is $\text{Detected Speed}/\text{Target/Takt Speed}$.
 - i. For 0 to 79% background is Red.
 - ii. For 80 to 94% background is Yellow.
 - iii. For 95 % and greater background is Green.
 - iv. **Please note:** If the production line is stopped and the sensor does not detect an object for about 15 seconds the **Speed: % On Target** field will turn to zero.
- c. **Job % Complete** field: This displays the ratio between **Detected Counts** and **Job Size** as a percentage. Formula is $\text{Detected Counts}/\text{Job Size}$.
 - i. For 0 to 99% background is Green.
 - ii. For 100% and greater background is Red.
 - iii. **Please note:** if no **Job Size** is entered the **Job: % Complete** field remains at zero.
- d. **Please note:** All percentage fields will continue to calculate and display if system is in both the START JOB and the END JOB modes, unless otherwise noted above.

6. Andon Lights

- a. There are four (4) Andon Lights on the **Tracker TR-1** screen, one in each corner of the screen. Please refer to readily available on-line Lean Manufacturing and 5S information for best practices and use of the Andon Lights.
 - i. Each Andon Light has three (3) states: Off, Steady On, and Blinking On.
 - ii. In the Off state, the color is faintly displayed so the operator knows where each color is located.
 1. **Green** Andon Light: Upper Left
 2. **Red** Andon Light: Upper Right
 3. **Blue** Andon Light: Lower Left
 4. **Yellow** Andon Light: Lower Right

7. Job Status Mode Screen

- a. The **Tracker TR-1** is pre-configured with 9 JOB STATUS modes: *Running, Job Set-up, Low on Product, Product Out, Call for Service, Down for Service, Shift Changeover, Break, Pause*. For each Job Status mode there is a predefined Andon Light combination turned-on:
 - i. *Running*: Solid Green
 - ii. *Job Set-up*: Flashing Green
 - iii. *Low on Product*: Solid Yellow
 - iv. *Down for Service*: Flashing Yellow
 - v. *Shift Changeover*: Solid Blue
 - vi. *Break*: Flashing Blue
 - vii. *Pause*: No Lights
- b. When job is started, system is placed into *Running* mode. If product is getting low, operator should click on *Low on Product*. If operator needs service assistance and line is still running, operator should click on *Call for Service*. If line stops, operator should click on *Down for Service, Shift Changeover, Break, or Pause*.
- c. If company would like to capture *Job Set-up* time, then click on START JOB, and then click on *Job Set-up*. When ready to run, click on *Running*.
- d. If in the middle of a job and JOB STATUS is not in *Running* mode, and the line is running, operator should click on *Running*.
- e. The JOB STATUS modes that are not highlighted white, indicate that when these modes are selected, the **Target/Takt Count** will not increment while in this mode. If one of these modes is selected the red background behind the **Target/Takt Count** and **Target/Takt Speed** will turn on, indicating no **Target/Takt Count** will increment. The red background will turn off if any of the white background **Job Status** modes are selected. No red background behind the **Target/Takt Count** and **Target/Takt Speed** indicates **Target/Takt Count** will increment.
- f. When operator clicks on START JOB, then the system starts collecting count and time values from start of job to end of job when END JOB is clicked. Each JOB STATUS mode has a timer field in the data file, so when the JOB STATUS mode is selected, the timer is increment for the duration the JOB STATUS mode is active.
- g. The JOB STATUS button display will intermittently flip between "Job Status" and the current selected JOB STATUS.



TROUBLE SHOOTING

Please note: all Tracker TR-1 Systems are fully inspected prior to shipment and will ship in good working condition.

1. Ensure TV is a 720p or compatible screen. The **Tracker TR-1** will work with higher resolution TVs, including 1080 systems, that can display 720p.
2. Ensure HDMI cable is working and correctly connected to the **Tracker TR-1** system and to the TV.
3. **DO NOT USE** any HDMI converters.
4. Ensure TV is turned on and set to the HDMI input that the HDMI cable from the **Tracker TR-1** system is plugged into.
5. If **Tracker TR-1** screen does not display, ensure steps 1, 2, and 3 above are correct. Turn **Tracker TR-1** system off for 20 seconds, and then turn on again.
6. If mouse or keyboard do not work: verify they are plugged in or wireless USB fob is plugged in. Turn **Tracker TR-1** off for 20 seconds, then turn on again. **Tracker TR-1** system cannot be ON when plugging in the USB or HDMI devices. The **Tracker TR-1** system needs to “discover” these devices when turning on or booting up.
7. If Sensor does not light up when hand placed in front, ensure the sensor cable is properly connected and screwed into sensor connector on back of the **Tracker TR-1**. Ensure sensor cable is properly connected and screwed into the sensor.

TECHNICAL INFORMATION

1. Power Requirements: 115V, 50/60Hz, 500ma FA
2. HDMI Connection: 720p or equivalent, Type A, Full Size Female Connector
3. USB Connection: 2.0, wired and wireless, Type A Female Connector
4. Sensor: Diffuse Reflective, NPN, 12 to 24 VDC, (24 Volt Provided By **Tracker TR-1**, 50mm (2”) range.
5. Sensor Connection: M12 Connector. Pin 1: Power, Pin 3: Ground/Common, Pin 4: Signal. Any style compatible sensor or relay input can replace provided sensor.
6. If utilizing a relay input, please note we provide the 24VDC power that needs to go through the dry contact side of user provided relay. Does not matter if user provided relay contacts are Normally Open or Normally Closed. **Tracker TR-1** will detect state change.